

**Perform Unit Level Maintenance (ULM) on Telephone Set TA-312/PT  
113-600-3017**

**Conditions:** Given telephone set TA-312/PT, battery BA-30 (two each), tool equipment TE-33, lint-free cloth and brush, cleaning compound trichlorotrifluoroethane, Department of the Army (DA) Form 2404, DA Form 2408-14, Technical Manual (TM) 11-5805-201-12, and DA Pamphlet (Pam) 738-750.

**Standards:** The standards are met when ULM is performed and DA Form 2404 and DA Form 2408-14 are completed; or the defective telephone set is evacuated to a higher maintenance level.

**Performance Steps**

1. Initiate DA Form 2404.
2. Perform routine checks. (Refer to TM 11-5805-210-12.)
3. Check telephone set TA-312/PT.
4. Check case, telephone set.
5. Check handset.
6. Complete DA Forms 2404 and 2408-14. (Refer to DA Pam 738-750.)

**Performance Measures GO NO GO**

**WARNING:** Trichlorotrifluoroethane fumes are toxic. Provide ventilation whenever it is used.

1. Initiate DA Form 2404. \_\_\_\_\_
2. Perform routine checks. (Refer to TM 11-5805-201-12.) \_\_\_\_\_
  - a. Clean, dust, and wash.
  - b. Check for frayed cables.
  - c. Store unused items.
  - d. Cover unused receptacles.
  - e. Check for loose nuts, bolts, and screws.
3. Check telephone set TA-312/PT. \_\_\_\_\_
  - a. Batteries.
  - b. Binding posts.
  - c. Battery compartment.
4. Check case, telephone set. \_\_\_\_\_
5. Check handset. \_\_\_\_\_
6. Complete DA Forms 2404 and 2408-14. (Refer to DA Pam 738-750.) \_\_\_\_\_

**Evaluation Guidance:** Score the soldier a GO if all performance measures (PMs) are passed. Score the soldier a NO-GO if any of PMs 2 through 5 are failed. If the soldier fails any PM, show what was done wrong and how to do it correctly. Have the soldier perform the PMs until they are done correctly.

**References**

**Required**

DA FORM 2404  
DA FORM 2408-14  
DA PAM 738-750

**Related**

SS0411